





PRESSURE SEQUENCE VALVES



PSVP

	Sequence with Reverse Check		
	Part No.	Flow (L/min)	Cavity
	PSVP-10-N-S-0-15	76	1025
	PSVP-10-N-S-0-30	76	1025



PSXS

	Sequence - External Pilot		
	Part No.	Flow (L/min)	Cavity
	PSXS-08-N-S-0-15	23	0830
	PSXS-10-N-S-0-15	46	1030



PSOS

	Sequence - Internal Pilot - Normally Open		
	Part No.	Flow (L/min)	Cavity
	PSOS-08-N-S-0-15	23	0830
	PSOS-10-N-S-0-15	46	1030



PSCS

	Sequence - Internal Pilot - Normally Closed		
	Part No.	Flow (L/min)	Cavity
	PSCS-08-N-S-0-15	23	0830
	PSCS-10-N-S-0-15	46	1030



BSXS

	Breaker Sequence - Ext. Pilot		
	Part No.	Flow (L/min)	Cavity
	BSXS-08-N-S-0-15	23	0830
	BSXS-10-N-S-0-15	46	1030



BSOS

	Breaker Sequence - Int. Pilot N.O.		
	Part No.	Flow (L/min)	Cavity
	BSOS-08-N-S-0-15	23	0830
	BSOS-10-N-S-0-15	46	1030



BSCS

	Breaker Sequence - Internal Pilot N.C.		
	Part No.	Flow (L/min)	Cavity
	BSCS-08-N-S-0-15	23	0830
	BSCS-10-N-S-0-15	46	1030

HLSV & HLSS

	Hi-Lo Sequence - Soft Shift, Poppet Type		
	Part No.	Flow (L/min)	Cavity
	HLSV-08-N-S-0-15	38	0825
	HLSV-10-N-S-0-15	76	1025
Hi-Lo Sequence - Soft Shift, Spool Type			
	HLSS-10-N-S-0-20	76	1025

PBVP

	Breaker Sequence - Reverse Check		
	Part No.	Flow (L/min)	Cavity
	PBVP-10-N-S-0-30	76	1025

For line mount bodies to suit the above cartridges refer to section "J". Use the cavity size to select the correct body type then choose the desired port size.