


# Complete Mount Valves


## ACCUMULATOR UNLOADING VALVES

### **VDA Series**

Aluminium body

This valve allows the pump to discharge to tank when the pressure setting is reached in U. The valve pressure is kept constant by an accumulator in A.





Part No. (with TR Spring option)	Ports BSPP	M.W.P. BAR	Spring	Dim. (mm)				Nom Flow	
			тν	TR	Α	в	С	D	L/min
VDA-38/TR.S.VRR	3/8″	250	5-110	100-250	95	60	120	-	25
VDA-12/TR.S.VRR	1/2″				108	60	120	-	50
VDA-34/TR.S.VRR	3/4″				120	60	145	-	100


## **AUTO-REVERSAL VALVES**


#### **VIA/AP** Series


Cetop 3 & 5 solenoid valve mount blocks


Aluminium body - Steel bodied units available on request - add suffix AC

The oil flow is automatically reversed from 'P to A' to 'P to B' and vice versa when the setting value of the pilot relief valve is reached.









Part No. (with TS Spring option)	Cetop Mount	M.W.P. BAR	Spring	Dim. (mm)				Nom Flow	
			τν	TS	Α	в	С	D	L/min
VIA/AP/6-38/VMP01/TS	3	210	5-100	50-200	80	45	57	25	30
VIA/AP/10-12/VMP02/TS	5				100	46	59	30	60